



Railing Care and Maintenance

Cleaning

Regular cleaning can be done by spraying down the railing with a garden hose,

If necessary using a solution of water and mild dish soap with a cloth, then hosing off once again will allow for a deeper clean

Scratches

Minor scratches and abrasions can be repaired by gently rubbing the affected area with fine steel wool, then buffing with a bit of WD-40 on a clean cloth.

Heavier scratches may be filled using a common furniture scratch repair pencil that closely resembles your Deck Tile colour. Examples include 'Paint Pal Putty Pencil' and 'Minwax – Blend-Fil' pencil. Please practice these techniques on an EON sample before attempting repairs on your finished product. ****Please note** that this tactic can minimize the look of the scratch but it will not remove the scratch entirely**

Winter Care

This railing system is invulnerable to the elements, so no winter maintenance is required

Please ensure you do not hit the posts or the railings with a shovel while clearing snow, with enough force this can cause cracking

Recommended Precautions

DO NOT use petroleum based products on the deck tiles

Avoid contact with Sunscreen, bug spray or bubble solution

DO NOT use a pressure washer on the railing system

DO NOT use any form of decking cleaner on the railing system. Mild dish soap with a cloth is sufficient to clean with